


WALL PLANKS INSTALLATION INSTRUCTION

1. Select orientation: horizontal, vertical or diagonal. Use pre-cut planks as Starter/End planks to alternate the shift of vertical seams.



Starter Plank

End Plank


2. Using a level, draw a line on the wall for the Starter Plank.




3. Prepare the finishing nails: either install the enclosed nail strip into the nail gun for 1" long and # 16 Gauge brad nails (adjust gun to deliver nails flush to the surface of wood), or chip nails from the strip with a utility knife for hammer installation (this is also recommended for hi-humidity areas).



4. Apply a starter plank at the line on the wall and affix it with the nails in each corner of the plank. Step at least 1 in. from each side or end of the planks. For full-length planks apply two more nails in the middle of the board. **Don't press planks against each other to leave a hair-size space to breathe.** If pressed they will be cupping and will pop out from the wall.



5. If you need to cut planks, use any wood saw (table saw or hand saw) or cut the furrow in the wood with a utility knife on both sides of the plank and break it against the edge of the table.



6. If you need to attach wall art or shelves on top of the wall planks, drill the holes and put hangers through the planks on your wall. Don't hang anything heavier than 0.5 lbs. on the planks themselves!

7. **NOT**-recommended installation options:

- **Double-sided sticky foam** – not recommended if used alone: sooner or later the planks may fall down if you don't secure planks with nails.
- **Adhesive or liquid nails** – not recommended as many adhesives will shrink or swell while hardening and wood will be cupping. If you anyway want to use adhesive, apply it along the length of the planks with three thin strips:

